

Analizzatore della Qualità dell'Energia per sistemi monofase e trifase bilanciati, dotato di 4 ingressi indipendenti per trasduttori.

Power Quality analyzer for mono and three phases balanced systems, that includes four independent input channels for transducers.



NanoVIP® TWO PLUS™ è un analizzatore della Qualità dell'energia portatile, compatto e potente per uso professionale; può essere utilizzato su reti monofase, bifase, trifase bilanciate, in bassa e media tensione.

In aggiunta ai canali elettrici, dispone di **4 canali indipendenti** per leggere qualsiasi tipo di trasduttore: **4..20mA, 0..1V o PT**.

NanoVIP® TWO PLUS™ is a portable Power Quality Analyzer, compact and powerful for professional use; it can work on single-phase, bi-phase and three-phase balanced, low and medium voltage networks.

In addition to the electrical channels, it has 4 independent channels for reading any type of transducer: 4..20mA, 0..1V or PT

POTENZA DI ANALISI E MASSIMA VERSATILITÀ

- Leggero, maneggevole, multilingua, con performance al top della sua categoria
- 1 canale di misura della tensione (1 fase + neutro) fino a 600V CAT III, con la possibilità di misurare anche tensioni continue
- 1 canale per le correnti con la possibilità di misurare anche correnti continue
- Precisione in corrente e tensione 0,25% + errore
- 4 canali indipendenti per trasduttori (4..20mA,
 0..1V, PT)
- 4 modalità precaricate per analisi di sistemi/impianti: chiller, pump, supply and sensors
- Batteria ad alta capacità per garantire la totale copertura lavorativa sotto batteria
- 20 allarmi (5 generici, 5 swells, 5 dips and 5 interruptions)
- Calcolo della spesa elettrica con fino a 4 tariffe

PRECISE IN MEASURE, VERSATILE, POWERFUL

- Lightweight, handy, multilingual, with top performance in its category
- 1 voltage measuring channel (1 phase + neutral) up to 600V CAT III, with the possibility to measure even continuous voltages
- 1 current channel with the possibility of measuring even continuous currents
- ✓ Currents and voltages accuracy 0.25% + FS error
- 4 independent channels for transducers (4..20mA, 0..1V, PT)
- 4 preloaded mode for system / plant analysis: chiller, pump, supply and sensors
- High-capacity battery to provide total under battery cover
- 20 alarms (5 generics, 5 swells, 5 dips and 5 interruptions)
- Calculation of electric charge with up to 4 rates



CASE:	
Dimensions	203x116x53mm
Material	ABS with self-extinguishing V0 grade
Protection class	IP30
Weight	580 g
DISPLAY:	
Dimensions	68x68mm
Туре	128x128 FSTN Negative dot matrix graphic LCD
Backlight	White LED
Languages	English - Spanish - Italian - German - French
KEYPAD:	
Туре	Membrane keypad with 10 double-function keys
POWER SUPPLY:	
External power supply	wall-plug switching; input 100-240VAC ±10% 47-63Hz with interchangeable plug; output 7.5VDC - 12W
Battery pack	4 x AA NiMh 2100mAh
Duration of the battery charge	>24h (wireless off)
CONNACTABLE SYSTEMS:	
Systems frequencies	50Hz – 60Hz – 400Hz
Single phase	✓
Two phase	✓
Three-phase, 3-wires, balanced	✓
Three-phase, 3-wires, unbalanced	-
4-phase, 4-wires, balanced	✓
4-phase, 4-wires, unbalanced	-
CONNECTIONS:	
Voltages	Flexible cables $L=1.5m$; $2.5mm^2$ - $36A$; $1000V$ CAT III - $600V$ CAT IV with a 4mm, 90° protected blade plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Voltages	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Voltages	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Voltages Currents Solar radiation	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Voltages Currents Solar radiation PT100	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Voltages Currents Solar radiation PT100 Anemometer	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors
Voltages Currents Solar radiation PT100 Anemometer Transducers	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS:	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max.
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc.
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated v V & I
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated v V & I Values and histograms up to the 50th order; up to 7th at 400Hz
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - - - - - - - - - -
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags Transients	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - - - - - - - - - -
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags Transients Unbalance	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated v V & I Values and histograms up to the 50th order; up to 7th at 400Hz Dips, swells & interruptions Overvoltages & overcurrents -
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags Transients Unbalance Test EN 50160	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated v V & I Values and histograms up to the 50th order; up to 7th at 400Hz Dips, swells & interruptions Overvoltages & overcurrents - v
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags Transients Unbalance Test EN 50160 Inrush current	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors - - - - Up to 4 independent (420mA, 01V, PT) V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, cosφ, φ, peaks, minimums, maximums, averages, max. demands, etc. Measured kWh, kVArh, kVAh, both absorbed that generated kWh, kVArh, kVAh, both absorbed that generated v V & I Values and histograms up to the 50 th order; up to 7 th at 400Hz Dips, swells & interruptions Overvoltages & overcurrents - v
Voltages Currents Solar radiation PT100 Anemometer Transducers FUNCTIONS: Traditional electrical analisys Neutral current Three phase counters Counters for each single phase Cogeneration Waveforms Harmonics Sags Transients Unbalance Test EN 50160 Inrush current DC measures	plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors Elcontrol Energy Net interchangeable amperometric sensors





Tariff bands	5	4
Energy cost	S	✓
IEC 61724 r	network parameters	✓
Test EN 82.	25	-
OSU™ (One	e Shot UPS)	-
Measurame	nt campaigns	unlimited, up to fill the memory card
MEASUREMENTS	S:	
Sampling fro	equency	128 samples per cycle (adaptive in 40Hz-70Hz range) 16 samples per cycle at 400HZ
Data record	l rate	1 sec.
Data storag	e rate	User selectable: 1", 5", 3", 1', 5', 15'
Type of con	nections available	Three-phase (3 or 4 leads balanced), two-phase (2 leads), and single phase grid
Type of grid	d which can be connected	Low and medium voltage (LV and MV)
VOLTAGE (1	TRMS)	
	Channels	2 channels with common neutral
	Input impedance	4 Mohm
	Scales	2
	Direct measurement	Phase-phase: 7-1000VAC 40-70Hz
		Phase-neutral: 5-600VAC 40-70Hz
		Aux: 5-1000VAC 40-70Hz, 10-1400VDC
	Measurement with VT	Ratio: 1-60000 Maximum value which can be displayed: 20MV
		Phase-phase: 1200VAC
	Permanent overload	Phase-neutral: 700VAC
		Aux: 1200VAC, 1700VDC
	Sensitivity	5VAC Phase-neutral, 7VAC Phase-phase, 10VDC
CURRENT (TRMS)	
	Channels	1 channel
	Input impedance	10KOhm
	Scales	4
	Measurement with current clamps	Ratio: 1-60000 Maximum value which can be displayed: 500KA
	Sensitivity	0,2% of F.S.
POWERS		
	Single phase power	Values < 999 GW, Gvar, GVA
	Total power	Values < 999 GW, Gvar, GVA
POWER COL	UNTERS	
	Maximum value before reset	9999999 kWh, kvarh, kVAh
ACCURACY		
	RMS voltages:	
	Scale 1	±0.25% + 0.1%FS ⁽²⁾ @ RMS V < 350VAC ⁽¹⁾
	Scale 2	±0.25% + 0.05%FS ⁽²⁾ @ RMS V > 350VAC ⁽¹⁾
	RMS currents:	
	Scale 1	±0.25% + 0.1%FS ⁽²⁾ @ RMS I < 5% IN clamp ⁽¹⁾
	Scale 2	±0.25% + 0.05%FS ⁽²⁾ @ 5% < RMS I < 20% IN clamp ⁽¹⁾
	Scale 3	±0.25% + 0.05%FS ⁽²⁾ @ 20% < RMS I < 50% IN clamp ⁽¹⁾
	Scale 4	±0.25% + 0.05%FS ⁽²⁾ @ > 50% IN clamp ⁽¹⁾
	Power	±0.5% + 0.05%FS ⁽²⁾
	Power Factor (PF)	±0.5°
	Frequency	±0.01 Hz (40-70Hz)
	Active power count (kW)	Class 0.5



Reactive power count (kVar)	Class 1
HARMONIC ANALISYS	Up to 50 th order
	Up to 7 th at 400Hz
ANALYSIS of EN50160 parameters	
Interruptions	>500mS
Dips	>500mS
Swells	>500mS
Transient ANALYSIS	
Swells and overcurrents	>150uS
Inrush current analysis	RMS continuous sampling every 2 periods – Duration 1, 2, 5, 10 sec.
COMMUNICATION:	
MRH™	✓
Server mode	-
Connectable MRH™ clients	-
Client mode	✓
Zigbee [®]	✓
Maximum distance outdoor	600m (point to point)
Maximum distance indoor	60m (point to point)
Mesh network	✓
Wireless to PC	-
USB	to PC
DATA STORAGE:	
Internal memory	64kB
External memory	Micro SD (2GB included)
OPERATING CONDITIONS:	
Operating temperature	-10 to +55 ℃
Storage temperature	-20 to +85 °C
Relative humidity	Max 95%
Maximum altitude a.s.l. (600V CAT III)	2000 m
EC COMPLIANCE:	
Directives	93/68/EEC (Low Voltage Electrical Equipment);
Directives	89/336/EEC and 2004/108/EC (EMC - Electromagnetic Compatibility);
	2006/95/EC - 72/23/EEC (LVD - Low Voltage Directive);
	2002/95/EC (RoHS - Restriction of Hazardous Substances);
	2002/96/EC and 2003/108/EC (WEEE - Waste Electrical and Electronic Equipment);
	IEC 61724
REFERENCE STANDARDS:	
Safety	EN 61010-1
Electromagnetic Compatibility (EMC)	EN 61326
	EN 61326/A1 EN 61326/A2
	EN 61326/A3
Temperature	IEC 60068-2-1 (Operating temperature)
·	IEC 60068-2-2 (Storing temperature)
Vibrations	IEC 60068-2-6
Humidity	IEC 60068-2-30 (Humidity)
Overload	IEC 60947-1





(+54) 11-6871-3274 INFO@ESPAELEC.COM.AR WWW.ESPAELEC.COM.AR











